





Truck Loading Platform TLP




EN 12811-1:2003

General Information

Work safely! Use appropriate Personal Protective Equipment (PPE)	
Check the distance and the height! Use truck loading platforms on both sides!	
Max. 2 persons at a time on the truck loading platform	
Do not use the truck loading platform for storage	
Inspect the truck loading platform before every use!	
Keep the truck loading platform free from snow, dirt/debris Remove dirt and snow	

Product Overview




No.	Item No.	Description	Picture
1	2079760	Truck Loading Platform (TLP)	
2	2079786	TLP handrail – long side	
3	2079787	TLP handrail – short side	

No.	Item No.	Description	Picture
4	2079770	TLP Stairway	
5	2079772Z-V	Stair Hand-rail – left	
6	2079772Z-O	Stair Hand-rail – right	

Truck Loading Platform (Single System)


Item no.: 2079760
812 kg



No.	Item No.	Description	Qty	Picture
1	2079760	Truck Loading Platform (TLP)	1	
2	2079786	TLP handrail – long side	2	
3	2079787	TLP handrail – short side	1	
4	2308301	Concrete foot	6	

Truck Loading Platform (Double System)


Item no.: 2 pcs of 2079760
2 x 812 kg



No.	Item No.	Description	Qty	Picture
1	2079760	Truck Loading Platform (TLP)	1	
2	2079786	TLP handrail – long side	2	
3	2079787	TLP handrail – short side	1	
4	2308301	Concrete foot	6	

TLP Stairway





Item no.: 2079761
70 kg




No.	Item No.	Description	Qty	Picture
1	2079770	TLP Stairway	1	
2	2079772Z-V	TLP handrail – long side	1	
3	2079772Z-O	TLP handrail – short side	1	

Assembling

1 Unloading with crane or with forklift




2 Check the distance between two platforms and the height of the platforms




Assembling



- 3** Put a piece of base plate (according to EN 74) under the platform's feet





- 4** Set the height of the platform



Pay attention to the inclination!








Max. inclination of the ground 2° (3,5 %)





Assembling

5 Connect all parts of the platform (platform, stairway and handrails)

a Singel system







b Double system



Working with the Truck Loading Platform


1 Driving the platform out (preparing for use)

2 screws for locking the platform in position!




Working with the Truck Loading Platform

1 Sliding the platform out (preparing for use)




Work only if all platforms are extended!




Working with the Truck Loading Platform


2 Truck loading or unloading



Do not use the platform for storage!




Not allowed for any person to be on the truck while loading or unloading!




3 Sliding platform back (before the truck leaves)

a




Unlock

b



c




Lock in position



Ready for the next truck!



Packing of Truck Loading Platform





• Tammet Oy •
Metallikutomonkatu 1
10600 Tammisaari, Finland

+358 201 450 201 • info@tammet.fi • tammet.fi