


# TLP Truck Loading Platform High




## General Information

Work safe!



Check the distance and the height!




Use platform on both sides!


Max. 2 Person



Do not use the platform for storing!




Inspect the platform before every use!




Keep the platform free from snow, dirt and any objects!




## Item Overview




Truck loading platform, module  
Code: 2079760H / 839 kg



Platform handrail  
– long side  
Code: 2079786 / 21 kg




Platform handrail  
– short side  
Code: 2079787 / 9 kg




Stair / 147 kg  
Code: 2079770H



Stair handrail / 10 kg  
Code: 2079772Z1-V (5) left  
Code: 2079772Z1-O (6) right








Platform gate (optional) 87 kg  
Code: 2079762-V (7) left  
Code: 2079762-O / right




Truck Loading Platform (Single System)


Code: 2079760  
839 kg







No.	Art. No.	Quantity	Description	Picture
1	2079760H	1	Truck loading platform module	
2	2079786	2	Platform handrail long side	
3	2079787	1	Platform handrail short side	
4	2308301	6	Concrete foot	




Truck Loading Platform (Double System)



[mm]


No.	Art. No.	Quantity	Description	Picture
1	2079760H	2	Truck loading platform module	
2	2079786	4	Platform handrail long side	
3	2079787	1	Platform handrail short side	
4	2308301	12	Concrete foot	









Stairway

Code: 2079761H  
163 kg




[mm]

No.	Art. No.	Quantity	Description	Picture
1	2079770H	1	Stair	
2	2079772Z1-V	1	Stair handrail - left	
3	2079772Z1-O	1	Stair handrail - right	





## Platform Gate (optional)

Code: 2079762-V (left)  
82 kg




[mm]

Push gate handle bar  
down and lock the gate




Locking pin

Closed stair gate





Open stair gate



Fix the gate to the platform


Fixing position



Closed gate



Open gate





Platform Gate (optional)

Code: 2079762-O (right)  
82 kg

Closed gate





Open gate



HAND CRUSH


[mm]

Push gate handle bar  
down and lock the gate




Locking pin

Closed stair gate





Open stair gate



Fix the gate to the platform


Fixing position



Closed gate



Open gate









Assembling

1 Unloading with a crane or with a forklift


a



b




2 Check the height of the platforms and the distance between two platforms




## Assembling

- 3** Put a piece of base plate (according to EN 74) under the platform's feet





Min. 150 cm<sup>2</sup>  
Min. width 120 mm  
Made of min. 6 mm material



- 4** Set the height of the platform



**Pay attention to the inclination!**








Max. inclination of the ground 2° (3,5%)






## Assembling

### 5 Connect all parts of the platform (platforms, handrails and stair)

#### a Single system




#### b Double system






max. 50 mm between  
two platforms

## Assembling

### 6 Installation of the gate (left & right gate)




Use a crane  
(with sling)  
for  
lifting the gate!






Working with the Platform

1 Driving the platform out and close the gate (preparing for use)




Work only if all platforms are driven out and gate closed!




[mm]

## Working with the Platform


### 2 Truck loading or unloading






**Do not use the platform for storing!**



**Not allowed for any person to be on the truck while loading or unloading!**






### 3 Driving the platform in and lift up the gate (before the truck leave)



Ready for  
the next  
truck!

Packaging



[mm]



Tammet Oy  
Metallikutomonkatu 1  
10600 Tammisaari

[www.tammet.fi](http://www.tammet.fi)  
[info@tammet.fi](mailto:info@tammet.fi)  
+358 201 450 201

